

## **ENGINEERED PRODUCTS TECHNICAL INFORMATION RELEASE** (POWER STRAPPING MACHINE DIVISION)

This Technical Information Release concerns a field repair program that involves the addition of a guard and safety labelling onto the PSD 109 and 119 strapping dispensers.

**DATE:** May 1, 2015

**PRODUCT:** Models PSD-109 and PSD-119 Strapping Dispensers.



DOES NOT INCLUDE the PSD-119 J and SJ Jumbo Coil Dispensers.

MANUFACTURERS: Signode, Signode Canada, Acme Packaging, Fleetwood and Cyklop.

#### TECHNICAL ISSUE ADDRESSED

There is a possible crush point on both the PSD-109 and PSD-119 strapping dispensers where the dancer arm comes into close proximity to the dispenser's "positive stop" area. A guard has been designed to cover the possible crush point.



**RECOMMENDED SOLUTION:** Add Internal Warning Sign 611298, Dispenser Guard 611299 and External Warning Sign 510486.



INTERNAL WARNING SIGN MOUNTED TO POST Part Number: 611298



**DISPENSER GUARD** Part Number: 611299

Dispenser guard fits both left hand & right hand dispensers.




**EXTERNAL** WARNING SIGN MOUNTED ON GUARD Part Number: 510486

©2015 SIGNODE SPD1824 07-29-15 Page 1

# **ENGINEERED PRODUCTS TECHNICAL INFORMATION RELEASE** (POWER STRAPPING MACHINE DIVISION)

### **DISPENSER GUARD INSTALLATION** (ESTIMATED INSTALLATION TIME - 15 MINUTES) PSD-109 & PSD-119 DISPENSERS:


- 1. Before installing the guard, follow your plant's lockout/tagout procedures for securing and isolating all power sources to the dispenser.
- 2. Attach internal warning sign as shown on guard side of post. Subsequently, the guard will cover sign.




3. Using two (2) 9/16" wrenches, loosen (DO NOT REMOVE) the hex head bolt.



**4.** Slide guard into place and re-tighten the bolt.





Hex head bolt with flat washer will be positioned outside the guard



Page 2 ©2015 SIGNODE SPD1824 07-29-15

# **ENGINEERED PRODUCTS TECHNICAL INFORMATION RELEASE** (POWER STRAPPING MACHINE DIVISION)

# **DISPENSER GUARD INSTALLATION** (ESTIMATED INSTALLATION TIME - 15 MINUTES) PSD-109 & PSD-119 DISPENSERS (Continued):

5. Attach external warning sign as shown.



6. Confirm that equipment is "all clear" and then reconnect power in accordance with the plant's lockout/tagout procedures.

Page 3 ©2015 SIGNODE SPD1824 07-29-15